

MAINTENANCE

ITEM	QTY	DESIGNATION	PART N°
Ball seals kit:			11 91 09 00 00
10	1	Ball seal (PTFE)	12 96 06 00 10
12	1	Main seal (PTFE)	11 14 02 00 06
Ball kit:			11 14 01 94 00
11	1	Ball (316)	12 96 06 00 09
Handle kit:			11 14 02 91 00
1	1	Screw M6x16 (st st)	-
2	1	Washer W6 (st st)	-
3	1	Handle (st st)	11 14 02 10 01
4	1	Bearing (PTFE)	12 96 06 00 13
5	1	O'ring (Viton)	70 10 03 02 08
6	1	Spacer (PTFE)	11 14 02 00 03
7	1	O'ring (FEP/Silicon)	70 10 15 00 66
8	1	Spindle Gasket (PTFE)	11 14 02 00 01
9	1	Spindle (st st)	11 14 02 00 02
Spindle seals kit:			11 14 01 92 00
4	1	Bearing (PTFE)	12 96 06 00 13
5	1	O'ring (Viton)	70 10 03 02 08
6	1	Spacer (PTFE)	11 14 02 00 03
7	1	O'ring (FEP+Silicon)	70 10 15 00 66
8	1	Spindle Gasket (PTFE)	11 14 02 00 01
Filter kit:			11 14 01 95 00
13	1	Filter (st st)	-
14	1	Lock Ring (st st)	-
Tools kit:			11 14 01 90 00
A	1	Spindle stop tool (Alu 2017T4)	11 14 01 90 01
B	1	Spindle seal tool (st st)	11 14 01 90 02

Nb Perolo recommends :

- The spindle seals should be changed simultaneously to maintain the ball valve spindle perfectly tight.
- Both ball gaskets should be changed simultaneously.
- Material of the parts are indicated for Stainless Steel Version. It may vary in HALAR Coated version. Please refer to HIGH CORROSION Catalogue for more details

